



Electric Vehicles Enzed

Electric Vehicles Enzed Ltd
C/- Mobility Manawatu 222 Ruahine Street
PO Box 4660, Palmerston North 4442
Phone 06 357 7943, FREE 0800 000 605
Email info@electricvehiclesenzened.co.nz
Web www.electricvehiclesenzened.co.nz

Unpacking & assembly instructions for the FourStar Golf Cruiser

If you have any questions or concerns whilst unpacking & assembling your FourStar Golf Cruiser please contact us

1. Remove carton off frame
2. Remove 6 x 10mm bolts holding upper & lower metal frames together
3. Remove accessory basket (contains manual, toolkit & charger)
4. Remove golf bag holder from transport frame (2 x 10mm bolts)
5. Lift off upper metal transport frame
6. Remove left & right foot plates (should be loose) using a Philips screwdriver
7. Remove 2 x bolts holding cruiser to lower metal frame
8. Refit foot plates making sure rubber mat is underneath (between chassis & footplate)
9. Remove protective bubble wrapping from cruiser
10. Lift handlebars and secure into place using clamp (near hinge)
11. Lift seat and remove cardboard then lower the rear shock absorber
12. Remove green knob and pin (lower rear shock absorber mount) and fit rear shock absorber into place using pin and green knob
13. With help, lift cruiser off lower transport frame OR using 3 x lengths of timber (or similar) place 1 board along the path of the rear wheel and 2 x boards to form a ramp for the front wheels and carefully roll cruiser off transport frame. Beware of mounting blocks under footplates that they clear the cruiser chassis
14. Remove knob & pin securing the rear shock absorber
15. Lift up the seat and locate seat stay under left hand side of the seat which hinges down and locates to hole on inner left side footplate
16. Remove 3 x black knobs holding battery cover in place
17. Connect battery plugs (x 2) and charger plug (x 1)
18. Re-fit battery cover panel
19. Re-fit rear shock absorber
20. Take for test ride (steering will be stiff at first but is better in the grass)
21. Remove black knob near top front of handlebars and fit front basket then refit knob
22. Remove large black knob near bottom front of handlebars and fit upper golf bag holder mount then attach lower golf bag mount (must be in this order)
23. Remove 2 x black knobs under rear of seat and fit sand bucket holder then refit both knobs
24. Clip score card holder onto middle of handlebars (requires a hard push to clip – clip one side on at a time)
25. Fit umbrella holder to handlebars (bracket already on right hand side)
26. Charge for 2 – 4 hours
27. Your FourStar Golf Cruiser is ready for use
28. Please follow charging instructions carefully as not doing so will void the warranty.